

# DockSide Radio

nets@docksideradio.com

www.docksideradio.com

941.661.4498

Marine Nets.				
U.S. East Coast				
Atlantic, Bahamas, Bermuda, Caribbean, Mexico, Panama				
Daylight Savings (Summer) Schedule				
Time		FREQ MHz Primary / Secondary	Upper / Lower Sideband	Net Name
UTC (GMT)	EDT East Coast US			
10:00	6:00	6.215	USB	<i>Caribbean (Uncontrolled 1000-1200)</i>
10:30	6:30	3.855	LSB	Trinidad /Caribbean WX - Eric 9Z4CP
10:30	6:30	3.815	LSB	Caribbean Emergency & Weather
10:40	6:40	4.045 / 8.137	USB	<i>Bahamas &amp; Caribbean WX (Chirs Parker)</i>
11:00	7:00	7.250	LSB	Caribbean MM (George KP2G - No Sunday Net)
11:20	7:20	7.096 / 3.696	LSB	Bahamas Weather
11:30	7:30	8.137 / 12.350**	USB	<i>Bahamas &amp; Caribbean WX (Chris Parker)</i>
11:45	7:45	7.268	LSB	Water Way / Cruising Club
12:00	8:00	8.170 / 8.146 / 8.164	USB	<i>Coconut Telegraph</i>
12:15	8:15	8.104	USB	<i>SSCA ( Seven Seas Cruising Assn. Stn KPK)</i>
12:30	8:30	8.152 / 8.146 / 8.164	USB	<i>Cruzheimers (8.152 Primary freq)</i>
12:30	8:30	8.137 / 12.350**	USB	<i>East Caribbean WX (Chris Parker)</i>
13:00	9:00	21.400	USB	Trans Atlantic
13:00	9:00	8.137 / 12.350**	USB	<i>Western Caribbean WX (Chris Parker)</i>
13:00	9:00	7.083	LSB	Cent Amer Bfst Club (Must be S of 20N to XMIT)
13:15	9:15	6.209 / 6.212 / 6.516	USB	SW Caribbean (6.209 Primary freq.)
13:30	9:30	2.582	USB	Bermuda Harbour
13:30	9:30	8.107 / 8167	USB	<i>Panama Connection Net</i>
14:00	10:00	6.209 / 6.212 / 6.516	USB	<i>NW Caribbean (6.209 Primary freq.)</i>
14:00	10:00	8.143 / 8.137/8.155/6C	USB	<i>Panama Pacific Net</i>
20:30	16:30	7.086	LSB	Caribbean Cocktail & WX (George KP2G)
21:00	17:00	8.152	USB	<i>Doo-Dah Net (Dick &amp; Judy - s/v St. Jude)</i>
21:30	17:30	12.350	USB	<i>Trans-Atlantic (SSCA)</i>
22:00	18:00	6.209 / 6.212 / 6.516	USB	<i>Caribbean vessels - PM Check-in</i>
22:30	18:30	3.815	LSB	Caribbean WX & Emergency
0:00	0:00	14.300	USB	24-hour Maritime Net coverage
As Needed	As Needed	3.935	LSB	Gulf Coast Hurricane
As Needed	As Needed	14325 / 3950	USB/LSB	Hurricane Watch *
<i>Blue (Italic Bold) = Marine SSB (Note: All Marine SSB nets are conducted on USB).</i>				
<i>Green (normal type) = HAM (Note: USB is used on 14mHz {20M} &amp; up; LSB is used on 7mHz {40M} &amp; below ).</i>				
<i>* Net activates whenever hurricane is within 300 miles of populated area.</i>				
<i>**Chris Parker Simulcasts on both frequencies.</i>				

Revised 23 Oct. 2018

Serving Boaters Coast to Coast