

DockSide Radio

nets@docksideradio.com

www.docksideradio.com

941.661.4498

Marine Nets

East Coast of U.S.

Atlantic, Bahamas, Bermuda, Caribbean, Mexico, Panama

Standard Time (Winter) Schedule

Time		FREQ MHz Primary / Secondary	Upper / Lower Sideband	Net Name
UTC (GMT)	EST East Coast US			
10:00	5:00	6.215	USB	<i>Caribbean (Uncontrolled 1000-1200)</i>
10:30	5:30	3.855	LSB	<i>Trinidad Emergency Net - Eric 9Z4CP</i>
10:30	5:30	3.815	LSB	<i>Caribbean Emergency & Weather</i>
11:00	6:00	7.250	LSB	<i>Caribbean MM (George KP2G - No Sunday)</i>
11:00	6:00	4.045 & 8.137**	USB	<i>Bahamas & Caribbean WX (Chris Parker)</i>
12:00	7:00	8.170 / 8.146 / 8.164	USB	<i>Coconut Telegraph</i>
12:15	7:15	8.104	USB	<i>SSCA (Seven Seas Cruising Assn. Stn KPK)</i>
12:20	7:20	7.096 / 3.696	LSB	<i>Bahamas Weather</i>
12:30	7:30	8.137 / 12.350**	USB	<i>Bahamas & Caribbean WX (Chirs Parker)</i>
12:45	7:45	7.268	LSB	<i>Water Way / Cruising Club</i>
13:00	8:00	21.400	USB	<i>Trans Atlantic</i>
13:00	8:00	7.083	LSB	<i>Cent Amer Bfst Club (Must be S of 20N to XMIT)</i>
13:15	8:15	6.209 / 6.212 / 6.516	USB	<i>SW Caribbean (6.209 Primary freq.)</i>
13:30	8:30	6.516- 6.224- 6.227-6.230	USB	<i>Cruzheimers Winter (6.516 Primary freq)</i>
13:30	8:30	8.152 / 8.146 / 8.164	USB	<i>Cruzheimers Summer (8.152 Primary freq)</i>
13:30	8:30	2.582	USB	<i>Bermuda Harbour</i>
13:30	8:30	8.107 / 8167	USB	<i>Panama Connection Net</i>
14:00	9:00	6.209 / 6.212 / 6.516	USB	<i>NW Caribbean (6.209 Primary freq.)</i>
14:00	9:00	8.143 / 8.137/8.155/6C	USB	<i>Panama Pacific Net</i>
21:30	16:30	7.086	LSB	<i>Caribbean Cocktail & WX (George KP2G)</i>
22:00	17:00	8.152	USB	<i>Doo-Dah Net (Dick & Judy - s/v St. Jude)</i>
22:00	17:00	6.209 / 6.212 / 6.516	USB	<i>Caribbean vessels PM Check-in</i>
22:30	17:30	3.815	LSB	<i>Caribbean WX & Emergency</i>
0:00	0:00	14.300	USB	<i>24-hour Maritime Net coverage</i>
As Needed	As Needed	3.935	LSB	<i>Gulf Coast Hurricane</i>
As Needed	As Needed	14325 / 3950	USB/LSB	<i>Hurricane Watch *</i>
<i>Blue (Italic Bold) = Marine SSB (Note: All Marine SSB nets are conducted on USB).</i>				
<i>Green (normal type) = HAM (Note: USB is used on 14mHz {20M} & up; LSB is used on 7mHz {40M} & below).</i>				
<i>* Net activates whenever hurricane is within 300 miles of populated area.</i>				
<i>**Chris Parker Simulcasts on both frequencies.</i>				

Revised 23 June 2017

Serving Boaters Coast to Coast.